



# KG SEAT ASSEMBLY

---

## I N S T R U C T I O N S

*For 2021 and Newer Models*

For more instructions visit [SpartanMowers.com](https://www.SpartanMowers.com) or contact your local dealer.

# KG SEAT ASSEMBLY - KIT PARTS



**Figure 1**

From Top Left to Bottom Right: Center Bracket with Cross-brace Tubes - Shock - Seat Bracket - Lower Bracket - Seat - Shock Bracket



**Figure 2**

- Plastic Roller x1
- 1/2" Copper Bushings x7
- 1/2" Bolt x6
- 1/2" Bolt Long x1
- 1/2" Nylon Lock Nuts x7
- 1/2" Washer x6
- 3/8" Bolt x2
- 3/8" Carriage Bolt x4
- 3/8" Nylon Lock Nuts x6
- Plastic Filler Inserts x4
- 4 mm Allen Head Screws x3
- Black Washers x3
- Shock Bracket Pin x1

## STEP 1

Install the 4-plastic filler inserts into the cross-brace tubes.



## STEP 2

Install the (2) ½" copper bushings into the center bracket.



## STEP 3

Assemble the lower bracket to the center bracket using the (2) ½" bolts and the nylon lock nuts as shown. Tighten securely.



## STEP 4

Install the (2) ½" copper bushings into the shock bracket.



## STEP 5

Assemble the shock bracket to the lower bracket using the (2) ½" bolts and nylon lock nuts as shown, tighten securely.



## STEP 6

Install the other ¾" bolt and nylon lock nut into the last holes and tighten until the threads are past the nylon part of the nut.



## STEP 7

Install the shock to the lower mounting bracket using the 3/8" bolt and nylon lock nut. Tighten down and then back off 1/4 turn. Then, install, the pin into the shock bracket and shock.

*This is adjustable for operator's preference.*



## STEP 8

Install the black plastic roller with the long 1/2" bolt and nylon lock nut in the slotted hole on the center bracket and tighten down. Be sure to allow black roller to spin freely. *This is adjustable for operator's preference.* Install the (2) 1/2" bolts and nylon lock nuts against the roller bolt and tighten securely. This helps hold the roller bolt from moving.



SPARTAN  
MOWERS

## STEP 9

Install the seat to the seat bracket by using the 3, 4mm allen head screws and black washers. *This is adjustable for operator's preference.*



## STEP 10

Install the seat bracket to the center bracket using the 4, 3/8" carriage bolts and nylon lock nuts. Tighten securely. ***This is adjustable for operator's preference.***



## STEP 11

Remove the soft grip knob located on the back of the mower.



## STEP 12

Slide the lower seat bracket notches onto the bolts as shown.



## STEP 13

Install the soft grip knob back onto the mower to hold the seat bracket in place.



